

Wallpaper

MEASURING GUIDE



eld!e
creative studio

Measuring Guide

Please take a moment to review this guide before starting to measure your walls.

If you feel unsure please consult a professional wallpaper installer for advice.

If you have a question, please get in touch and I will do my best to find an answer for you!

Cat Bellini

cat@eldiecreative.com

How to measure your wall?

Getting accurate measurements is the most important first step for your new wallpaper. Ordering it in one batch is important to ensure colouring of all panels are consistent.

General Tip for All Walls

Always add 10 cm to both the width and height of your measurements. This allows for minor variations in wall shape or level and ensures your wallpaper covers the entire area – edge to edge, top to bottom.

Option 1: Standard Walls

If your wall is clean and simple – no obstacles, corners, or cut-outs – this is your method.

How to measure:

- Measure the full width of the wall from edge to edge (in cm).
- Measure the *full* height from the floor to the ceiling (in cm).
- Add 10 cm to both width and height for safety.

Tip: Use a metal tape measure for more accurate results and double-check your numbers!

Option 2: Walls with Slopes, Doors, Windows or Obstacles

Walls aren't always straightforward – and that's totally fine. If your wall has a sloped ceiling, built-in shelving, windows or a door, you'll still measure the full rectangle around it.

How to measure:

- Ignore any doors, windows, or features – pretend they're not there.
- Measure the widest part of the wall and the tallest point.
- Add your 10 cm safety margin to both dimensions.
- **Tip:** This gives you full wallpaper coverage. Later, you (or your installer) can trim around doors, powerpoints or windows for a perfect fit.

Option 3: Multiple Walls or Corners

Want your wallpaper to wrap around a corner or cover more than one wall? Here's how to tackle it.

How to measure:

- Measure the width of each wall individually (in cm).
- Measure the maximum height across all walls.
- Add 10 cm to each width and to the max height.

Extra Measuring Tips:

Always use centimetres for consistency.

If your wall is tiled, bricked, or textured, measure from the actual surface (not from mouldings or trims).

Don't worry if your walls aren't perfectly square – that's exactly why the 10 cm buffer is important.